CHATA PIROHOVIE / KRPÁČOVO

BVF floor-heating thermostat

A BVF 801 WiFi thermostat on the bathroom wall controls the floor heating. It is normally set to around 20 °C for guests.

HOW TO USE / GUEST INSTRUCTIONS

1. Check the thermostat display in the bathroom.
2. If switched off, use the power button.
3. Use + and − to adjust the target temperature a little at a time.
4. Underfloor heating responds gradually.
5. Do not alter scheduling, sensors or Wi-Fi. Contact the host if controls are locked.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.