CHATA PIROHOVIE / KRPÁČOVO

Samsung microwave

The Samsung microwave is located in the pantry. Use it for reheating food and defrosting. It has simple mechanical controls and a turntable. Please leave it clean after use.

HOW TO USE / GUEST INSTRUCTIONS

1. Use a microwave-safe container without metal and make sure the turntable is in place.
2. Cover food with a microwave-safe cover, never a sealed container.
3. Select the power and time suitable for the food.
4. Beware of steam and hot dishes.
5. Never run the microwave empty; wipe the interior clean. Location: pantry.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.