CHATA PIROHOVIE / KRPÁČOVO

Sencor electric kettle

The stainless-steel 1.7-litre Sencor kettle is located in the kitchen.

HOW TO USE / GUEST INSTRUCTIONS

1. Fill with fresh water between MIN and MAX.
2. Close the lid and place on the base.
3. Switch on; it turns off automatically when boiled.
4. Be careful when pouring hot water.
5. Let it cool after use and never run it empty.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.