CHATA PIROHOVIE / KRPÁČOVO

SwitchBot Lock Ultra with keypad

The entrance uses a SwitchBot Lock Ultra and a SwitchBot Keypad. The host supplies a unique PIN for your stay. Never share your access code with others.

HOW TO USE / GUEST INSTRUCTIONS

OUTSIDE: Enter the PIN provided for your stay and confirm using the button indicated on the keypad (usually ✓). Open the door after it unlocks.

INSIDE: Rotate the thumbturn manually to lock or unlock. The central quick button can also operate the lock according to its configuration.

Always check that the door is securely locked before leaving. Contact the host if the PIN does not work.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.