CHATA PIROHOVIE / KRPÁČOVO

Tefal toaster

The two-slot Tefal toaster has adjustable browning levels and a STOP button.

HOW TO USE / GUEST INSTRUCTIONS

1. Insert bread and choose a browning level.
2. Lower the lever and wait for the bread to pop up.
3. Use STOP to interrupt.
4. Never insert metal objects or use the toaster near water.
5. Once cooled, empty the crumb tray if necessary.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.