CHATA PIROHOVIE / KRPÁČOVO

Wood-burning fireplace

The living-room fireplace requires caution and dry firewood. Never clean a hot firebox.

HOW TO USE / GUEST INSTRUCTIONS

Before lighting, prepare a small amount of dry firewood and a suitable firelighter.

1. Never handle hot ashes. Only remove ashes when the firebox, grate and ash drawer are completely cold. If unsure, leave the ashes and ask the host.
2. For fully cold ashes, use a shovel and a lidded metal bucket. Keep this container away from combustible material.
3. Place suitable kindling, a firelighter and no more than two small logs in the firebox. Do not overload it.
4. Light the fire, then close and latch the firebox door. Use only the designated air control. Keep the ash drawer door closed to prevent overfiring.
5. Never leave a fire unattended. Keep children away from hot glass. Ensure the fire has died out before leaving. Contact the host if unsure.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.