CHATA PIROHOVIE / KRPÁČOVO

Haier washer-dryer

The Haier combined washer-dryer is useful for family holidays and sports trips. Choose the appropriate wash or wash-and-dry program and follow garment care labels.

HOW TO USE / GUEST INSTRUCTIONS

1. Sort laundry by garment labels and do not overload. Drying capacity is lower than washing capacity.
2. Add detergent to the correct compartment.
3. Select a suitable program and start.
4. Wait for the door to unlock before opening.
5. Leave the door and detergent drawer ajar after use. Do not run servicing modes.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.