CHATA PIROHOVIE / KRPÁČOVO

Nespresso KRUPS Essenza Mini coffee machine

The compact Nespresso KRUPS Essenza Mini prepares espresso and lungo. Use Nespresso Original-compatible capsules only. Find it in the kitchen or pantry.

HOW TO USE / GUEST INSTRUCTIONS

1. Fill the tank with fresh cold drinking water.
2. Press the espresso or lungo button and wait until ready.
3. Lift the lever, insert a Nespresso Original capsule, then close.
4. Press espresso or lungo. Afterwards lift the lever to eject the capsule.
5. Empty the drip tray and used-capsule container after use.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.