CHATA PIROHOVIE / KRPÁČOVO

Tefal UltraCompact 3-in-1 sandwich maker

The Tefal UltraCompact 3-in-1 makes toasted sandwiches, panini and waffles with exchangeable plates. Clean it after use.

HOW TO USE / GUEST INSTRUCTIONS

1. Change plates only when the appliance is off and cool.
2. Place food between the plates and close.
3. Take care when opening hot plates and when steam escapes.
4. Disconnect, cool and clean the plates after use.
5. Never leave the appliance on unattended.

This short guest guide does not replace the manufacturer’s official instructions. If controls differ or you are unsure, stop and contact the host.